

# Sensors



Emissions sensor |  
T413985



Aftertreatment  
pressure sensor |  
T414354



Particulate sensor |  
T415131



Particulate sensor |  
T419949



Emissions sensor |  
T413996



Particulate sensor |  
T417907



Emissions sensor |  
185746151



Air pressure sensor |  
T405054



Air pressure sensor |  
T410249



Air pressure sensor |  
T400066



Air pressure sensor |  
T411850



Air pressure sensor |  
U5MK1090



Air pressure sensor |  
T413922



Air pressure sensor |  
T411944



Air pressure sensor |  
T407269



**Air pressure sensor |  
U5MK1169**



**Crankshaft speed  
sensor | U5MK1234**



**Fuel pump speed  
sensor | U5MK1086**



**Fuel pressure sensor |  
T419554**



**Fuel pressure sensor |  
T415770**



**Fuel pressure sensor |  
T400040**



**Fuel pressure sensor |  
T410762**



**Fuel pressure sensor |  
U5MK1236**



**Oil pressure sensor |  
2848062**



**Oil pressure sensor |  
2848A013**



**Oil pressure sensor |  
185246060**



**Oil pressure sensor  
185246190**



**Oil pressure sensor |  
T421762**



**Oil pressure sensor |  
185246180**



**Oil pressure sensor |  
2846071**



**Oil pressure sensor  
U85246210**



Oil pressure sensor |  
2848A071



Oil pressure sensor |  
185246280



Oil pressure sensor |  
2848131



Oil pressure sensor |  
U5MK1074



Oil pressure sensor |  
U85246310



Oil pressure sensor |  
2848A051



Oil pressure sensor |  
185246240



Oil pressure sensor |  
2848063



Oil pressure sensor |  
T406711



Oil pressure sensor |  
T407180



Oil pressure sensor |  
T416282



Oil pressure sensor |  
T411849



Oil pressure sensor |  
2755D004



Oil pressure sensor |  
185246170



Oil pressure sensor |  
U5MK1088



Water in fuel sensor |  
T417241



**Water temperature  
sensor | 2848A127**



**Water temperature  
sensor | 385720500**



**Water temperature  
sensor | 2755882**



**Water temperature  
sensor | 2755A006**



**Water temperature  
sensor | T407354**



**Water temperature  
sensor | 2874A018**



**Water temperature  
sensor | U5MK1091**



**Water temperature  
sensor | T419947**



**Water temperature  
sensor | KRP1688**



**Water temperature  
sensor | 385720520**



**Water temperature  
sensor | KRP1687**



**Water temperature  
sensor | T410501**



**Water temperature  
sensor | T419380**



**Water temperature  
sensor | 185746120**



**Water temperature  
sensor | 385720230**



**Water temperature  
sensor | 185746110**



**Water temperature  
sensor | 185746100**



**Water temperature  
sensor | T419414**



**Water temperature  
sensor | T419976**



**Water temperature  
sensor | 2848A111**



**Water temperature  
sensor | T411973**



**Water temperature  
sensor | T415904**



**Water temperature  
sensor | 185746130**



**Water temperature  
sensor | T407268**



**Water temperature  
sensor | T417897**



**Water temperature  
sensor | T409471**



**Water temperature  
sensor | 2848A128**



**Water temperature  
sensor | 385720530**



**Water temperature  
sensor | T405451**



**Water temperature  
sensor | T413978**